
	Alcatel·Lucent	Display and display keys Contains several lines and pages providing information on calls and the functions accessible via the 6 keys associated with the words on the screen.
one	Handset Adjust the tilt of the screen Adjust the tilt of the screen	 Transfer icon: pressing the key next to this icon allows you to program or change the transfer function. Headset connected. Appointment programmed. Silent mode activated. Telephone locked. Display keys: pressing a display key activates the function shown associated with it on the screen.
Touch 4028 Phone / 4029 Digital Phone		 Navigation OK key: used to validate your choices and options while programming or configuring. C Left-right navigator: used to move from one page to another. C Up-down navigator: used to scroll through the content of a page. I Back/Exit key: to return to previous menu (short press) or return to first screen (long press); during a conversation, provides access to welcome screens (Menu, Info,) and to return to the conversation icon screens. Welcome screens Menu page: : contains all functions and applications accessible via the keys associated with the words on the screen. Perso page: : contains call line keys (allowing supervision of calls) and programmable call keys.
ch 402	Socket for connecting headphones or a Alphabetic keypad Hands-free / Loudspeaker unit	Info page: : contains information on the telephone and the status of its functions: name, telephone number, number of messages, activation of transfer function, appointment reminder, etc.
Alcatel-Lucent IP Touc	 Audio keys Hang-up key: to terminate a call. Hands-free/Loudspeaker Key: to make or answer a call without lifting the receiver. It in hands-free mode or headset mode (short press). flashing in loudspeaker mode (long press). Intercom/Mute key: During a conversation: press this key so that your correspondent can no longer hear you. Terminal idle: press this key to answer calls automatically without picking up the receiver. To adjust the loudspeaker or handset volume up or down 	 Call display Incoming call. Incoming call.
	Extension unit An extension unit can be fitted to your tele-	switch from one call to the other by pressing the display key associated with each call.
www.alcatel-lucent.com	An extension unit can be inteed to you which can be configured as function keys, line keys, call keys etc. To affix labels ; push the holding strip of the unit backwards to you and lift it. Install the la- bel under the keypad, in the housing designed for, and place the keypad back into position.	 Function keys and programmable keys Guide key: used to obtain information on functions of the 'menu' page and to program key of the 'perso' page. Messaging key to access various mail services If the key flashes, a new voice message or a new text message has been received. 'Redial' key : To access the 'Redial' function.
www.al	To avoid accidentally damaging the set telephone line connector, make sure you position the cord correctly in the compartment intended for this purpose.	Programmable key (FI and F2 keys) Lit when the function associated with the key is activated.

Customize your terminal	
The customization functions of the telephone are access	ed from the Menu page. <u></u> <u>Menu</u>
Modifying your personal code	
menu Settings	
reach the 'menu' page	
or Phone Password	follow informations displayed on the screen
Lock / unlock your telephone	Menu
	2 ²⁴ 3 ⁴⁴ 5 ¹⁴ 6 ¹⁴
page inform	ding the displayed ations, enter your word or confirm
your telephone is locked/unlocked	
Adjusting the audio functions	Menu ,
Menu Pho	one
reach the ' menu ' page	
Adjust ringing (melody, v following instructions screer	displayed on the
Adjusting screen brightness	Menu
Menu Settings	Contrast
reach the ' menu' page	
AND/OR CONTRACTOR OR	8
increase or decrease the o	contrast

Using your telephone



Divor			
Diver	t your calls to anothe	er number	
3		242 34 574 6m	®
	press the key associated with the type of diversion required (immediate, if busy, if no reply etc.)	dial the destination number	press the ok key if programming is not automatically recorded;
Diver	ting calls to your void	e mailbox	
3			
	press the key associate with 'divert to voice mailbox'	•	press the ok key if programming is not utomatically recorded
When	n you return, cancel a	ll diversions	
3		\rightarrow	if necessary, confirm cancellation of the diversion
F	press the key next to 'cano deactivate the diversion		
Direct	tory		
Using	call by name		
A 7 Q 5	→ O	•	GR
enter the first letters of the n	select the nam ame displaye		make the call
			make the call
letters of the n		d list om the	make the call
OR OK	ame displaye	d list om the	- (7)
OR OK	ame displaye	d list om the	make the call
Progr	ame displaye	om the st orogrammed) or	make the call Perso follow informations displayed on the screen
Progr	ame displaye select the name fr displayed lis am your call keys press a call key (not p	om the st rogrammed) or rey (fl or f2)	make the call Perso follow informations displayed on the screen
Progr	ame displaye	om the st rogrammed) or rey (fl or f2)	make the call Perso follow informations displayed on the screen

Divert your calls to another number


During a conversation

Sending DTMF signals

During a conversation you sometimes have to send DTMF signals, such as with a voice server, an automated attendant or a remotely consulted answering machine. The function is automatically cancelled when you hang up.



conversation



During a conversation, to call a second person.



number for your call

dial

Transferring a call


During a conversation, to transfer the call to another number:

2000 3 514 6

called

Transfer

number to be



This document describes the services offered by the Alcatel-Lucent IP Touch 4028 Phone and 4029 Digital Phone sets connected to an Alcatel-Lucent OmniPCX Office or Alcatel-Lucent OmniPCX Enterprise Communication Server system.

For more information, see the user manual for your Alcatel-Lucent IP Touch 4028 Phone (IP set) or 4029 Digital Phone (digital set) set. Contact your installer.

Warning: never place your telephone in contact with water. To clean your telephone, you may however use a damp soft cloth. Never use solvents (trichlorethylene, acetone, etc.) which may damage the plastic parts of your telephone. Never spray it with cleaning products. The ear piece and microphone area of the handset may attract metallic objects that may be dangerous

for the ear

The wording is not contractual and may be subject to change. Some functions of your telephone are controlled by a software key and the configuration of the unit.

EC countries: we, Alcatel-Lucent Enterprise, declare that the Alcatel-Lucent IP Touch 4028 Phone and 4029 Digital Phone products comply with the essential demands of Directive 1999/5/CE of the European Parliament and Council. A copy of the original of this declaration of compliance can be obtained from your installer.

Collection of these products at the end of their product life must be done selectively.



Alcatel, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent. All other trademarks are the property of their respective owners.The information presented is subject to change without notice. Alcatel-Lucent assumes no responsibility for inaccuracies contained herein. Copyright © 2007 Alcatel-Lucent. All rights reserved.



you want to call from the programmed call keys

correspondent